



**Notes:**

- Use appropriately sized cable for the application
- Use appropriate cable for hazardous zones where required
- It is recommended to use ferrules on all communication wires
- Gland all cables that enter the cabinet
- Seal all unused holes in the cabinet
- External aerial cable (option) screws into RF socket on cellular modem
- Always replace electrical covers



**OPT INSTALLATION WIRING DIAGRAM**  
**Gilbarco Pump Connections**

**REVISION B**

DATE : 29 August 2014