



Notes:

- Use appropriately sized cable for the application
- Use appropriate cable for hazardous zones where required
- It is recommended to use ferrules on all communication wires
- Gland all cables that enter both cabinets
- Seal all unused holes in both cabinets
- External aerial cable screws into RF socket on cellular modem